Livingstone Tower LT 208 - Audio Visual Equipment - Operating Instructions

University of Strathclyde

This room has facilities to play DVD, VHS Video and display the output from a laptop computer through the ceiling-mounted data projector and sound system.

Using the data projector with a laptop



The projector is controlled from the 8 button panel mounted on the wall.

1: **To start**, switch on the data projector by pressing the **ON** button.

2: Press the **PC1** button to select your laptop.

3: Then lower the projection screen using the **Down** button.

4: Now plug the **VGA cable** into the **monitor socket** on your laptop.

5: If your presentation includes **audio** you must also plug-in the **mini-jack plug** into the **green headphone socket** on your laptop.

6: You should now see your desktop projected on screen. If you cannot see the image you may have to "**toggle**" your laptop. Please refer to the table below to find the correct key combination for your particular model.

IBM + Sony	Fn + F7	Toshiba	Fn + F5
Dell + Epson	Fn + F8	Panasonic + NEC	Fn + F3
Hewlett Packard	Fn + F5	Fujitsu	Fn + F10
Sharp	Fn + F5	Apple	F7

7: Please **switch the projector off** when you have finished, using the **OFF** button on the control panel.

*** Please note** that the **maximum resolution** the University projectors support is **1024 x 768**

Using the DVD player

The VHS/DVD player is housed in the cabinet underneath the 8 button control panel.

1: Switch on the data projector by pressing the **ON** button.

2: Lower the projection screen using the **Down** button.

3: Switch the VHS/DVD player **ON**.

4: Select **VIDEO1** on the control panel and insert your disc or VHS tape.

5: Adjust the volume level using the buttons **VOLUME +** and **VOLUME -** on the control panel.

6: Please **switch the projector off** when you have finished, using the **OFF** button on the control panel.

7: Please **retract the projection screen** when you have finished.

ASSISTANCE: **If you experience difficulty with the AV equipment or wish to report a fault please contact Learning Services on:**

Tel: ext. 5999 (or 0141 548 5999). **Email: LS-roomsupport@strath.ac.uk** **Web: www.learningservices.strath.ac.uk**